

TITAN

GREAT OUTDOORS



OWNER'S MANUAL

MPN(s): 29CFP, 39CFPLW

SKU(s): 899833, 899839


UPC(s): 049008268500, 049008268449

PARTS DIAGRAM & INSTRUCTIONS

IMPORTANT!

Please read and follow ALL instructions before assembling or using this product, particularly the safety statements. Failure to follow instructions and warnings could result in damage to property, serious injury, or death.

Parts Identification List



Instructions:

- 1) Place Large Ring (1) upside down (holes facing up).
- 2) Place and lightly fasten each Leg (3) to Large Ring (1) with Bolt (8) using Phillips Head Screwdriver. **DO NOT FULLY TIGHTEN THE BOLTS!**
- 3) Insert Small Ring (5) into U-shaped bracket of each Leg (3). Lightly fasten each Leg (3) with Bolt (8) using Phillips Head Screwdriver. **DO NOT FULLY TIGHTEN THE BOLTS!**
- 4) Invert assembly so that Large Ring (1) is on top. Tighten all 8 Bolts (8) securely at this time.
- 5) Place Fire Bowl (7) into Large Ring (1).
- 6) Place Screen (2) onto Fire Bowl (7), using the recess in the bowl for alignment.



WARNING!

- Outdoor Use Only! Never use in an enclosed area. Using this product in unventilated areas can endanger your life.
- Keep away from all combustible materials including gasoline and other flammable liquids and vapors.
- NEVER use flammable accelerants, such as: gasoline, alcohol, paint thinners, kerosene, etc. to start a fire. Serious injury or property damage could result.
- Use on a level, noncombustible surface only.
- Keep away from house, garage, balconies, or overhangs.
- Avoid using during dry or windy conditions.
- Keep out of reach of children.
- Do not overfill or use to burn leaves or trash.
- Exercise the same care you would with an open fire.
- Never leave unit unattended while hot or in use.
- Completely extinguish fire before leaving.
- Use heat-proof gloves to handle or move. Ashes can remain hot for a long time after fire is extinguished.
- Dispose of cold ashes properly.

Contact local authorities regarding possible burn restrictions prior to using product!



FIRE PIT MAINTENANCE

Cleaning Instructions:

- Fire bowl may be cleaned with water and mild detergent. Do not use abrasive detergents or pads to clean fire bowl.
- Periodic maintenance may be required to return painted steel surfaces to original appearance. Remove any rust with sandpaper or steel brush and repaint with grill paint suitable for high-temperature surfaces. Follow manufacturer's instructions.
- Fire bowl may change colors over time with use. This is normal and expected.





*This concludes the
assembly of your
product.*

*Make sure to tighten
all nut-and-bolt
combinations before
use.*

Enjoy!

NEED HELP?

CONTACT US FIRST.

1 (800) 605-8241

info@titandistributorsinc.com / www.titangreatoutdoors.com

Business Hours: Monday–Friday • 8:00 a.m.–5:00 p.m. (CT)

