




Sling Log Rack

Owner's Manual



MPN: HRACK_S
SKU: 899910
UPC: 049008265820



Titan Distributors Inc.
141 Eastley St. Ste. 113
Collierville, TN 38017

1 800-605-8241

info@titandistributorsinc.com

www.titandistributorsinc.com

ASSEMBLY INSTRUCTION


1. Attach the *Left Rack (1)* to the *Legs (3)*:

Attach the Left Rack (1) to the Legs (3) using the Screws (4). Align a Leg (3) and the Left Rack (1) by the holes drilled through them, then screw an Screw (4) through the hole until it is secure. Repeat this process with the remaining Leg (3).

2. Attach the *Right Rack (2)* to the *Legs (3)*:

Attach the Right Rack (2) to the Legs (3) using the Screws (4). Align a Leg (3) and the Right Rack (2) by the holes drilled through them, then screw an Screw (4) through the hole until it is secure. Repeat this process with the remaining Leg (3).

PARTS DIAGRAM



Part Number	Part Description	Quantity
1	Left Rack	1
2	Right Rack	1
3	Leg	2
4	Screw	4



NEED HELP?
CONTACT US FIRST
1(800)-605-8241

info@titandistributorsinc.com / www.titandistributorsinc.com
Business hours: Monday - Friday • 8am - 5pm Central

