




899571 - DUELTRGT_AE, 899561 - DUELTRGTHD_AE

AR500 DUELING TREE STEEL TARGETS





UNBOXING

- A.** 3/8" AR500 SHOOTING TREE TARGET (6)
- B.** 1/2" AR500 SHOOTING TREE TARGET (6)

IMPORTANT PRODUCT INFORMATION

WARNING:

- NEVER shoot steel core, steel jacket, solid copper ammo, or magnum rounds at the shooting target
- Do NOT shoot the target with BB's, pellets, or air soft. They do not have enough force to splatter and will ricochet
- Do NOT shoot any closer than 100 yards with a rifle and 10 yards with a handgun
- Do NOT shoot a caliber larger than .308 at the shooting target
- ALWAYS wear eye and ear protection while shooting at the target

SUGGESTIONS:

- To prevent injury from a ricochet wear shooting glasses and protective clothing. Ear protection is also highly recommended when shooting.
- To avoid pitting, keep the speed of bullet impact below 3000 fps.
- To lessen ricochet, keep the speed of the bullet impact above 1500 fps.
- Flip your Titan shooting target to prolong target life.

MINIMUM SHOOTING DISTANCES PER CALIBER:

- 10 Yards
 - .22 Rim Fire
 - 9mm
 - .38 Spl
 - .44 Spl
 - .45 acp

12 YARDS

- .357
- .40 SW
- Shotgun with lead bird shot

20 YARDS

- Shotgun with standard velocity 00 buck shot

50 YARDS

- Shotgun with standard velocity slug

100 YARDS

- .30 to 30

150 YARDS


- .308


SUGGESTED HANGING METHOD:

- Hang the Titan shooting target at an angle like the target shown in the below diagram. This will reduce harmful ricochet.

SAFETY USE

For safest use of the Titan shooting target, stand in front of the target with a minimum of the suggested shooting distance for your caliber between the Titan shooting target and yourself, then aim directly at the center of the target.





WARNINGS



Heavy object. Use lifting aids and proper lifting techniques when moving.



Sharp objects may be involved. Use precaution and protection.



Choking hazard. Small parts - Please exercise caution if small children or pets are present.

Acknowledgement of Risk & Release of Liability

The use of any equipment, including this one, involves the potential risk of injury. Apart from any warranty claim that might be presented for a claimed defect in material or workmanship of the product, you accept and assume full responsibility for any and all injuries, damages (both economic and non-economic), and losses of any type, which may occur, and you fully and forever release and discharge Titan, its insurers, employees, officers, directors, associates, and agents from any and all claims, demands, damages, rights of action, or causes of action, present or future, whether the same be known or unknown, anticipated, or unanticipated, resulting from or arising out of the use of said equipment. This equipment must be used with care by capable and competent individuals under supervision, if necessary.

Time Limited Warranty: Terms, Exclusions & Limitations of Remedies

This product comes with a one (1) year limited warranty that can be found at www.ashandemberoutdoors.com/warranty.html. Please review the same for all details regarding the Titan Limited Warranty.

THE TITAN LIMITED WARRANTY FOUND AT WWW.TITANGREATOUTDOORS.COM/WARRANTY.HTML IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE, EACH OF WHICH IS HEREBY DISCLAIMED.

ASH & EMBER

Need help? Contact us first.

PHONE

1-888-794-1455

EMAIL

info@ashandemberoutdoors.com

ASH & EMBER

www.ashandemberoutdoors.com